



- HVAC unit literature. Actual job site dimensions have not been taken. Field alterations an reinforcements may be required of site dimensions vary from literature.
- Before ordering curb adapter, contractor must confirm that dimensions of existing curb on job site matches dimensions of existing curb on this drawing.
- Before new HVAC unit is set in place inspect structural stability of existing curb and building's roof load capability. Reinforce if required.
- All curb adapters will increase the system's external static pressure and must be included when calculating unit requirements.
- 5) Follow all local and state laws when installing curb adapters.



## MODULAR METAL FABRICATORS INC.

CURB ADAPTER WCC018060 TO RJNLA060

SIZE FSCM NO. PART NO. SDRHEEMAD243

SCALE SHEET